



# INSTALLATION INSTRUCTIONS

## LATERAL CONNECTION POLYPROPYLENE SADDLES

1. Clean pipe in the area where the saddle will be installed.
2. Insert the bolt heads into the bottom half of the saddle and position the saddle bottom into place on the main.
3. Ensure gasket is in position in the top half of the saddle and slide top half of the saddle over the bolts.
4. Start the nuts onto the bolts and tighten while ensuring that the two halves of the saddle are drawn down evenly onto the main.
5. Drill hole in the main with a hole saw taking care to ensure that the hole saw bit does not engage the threads in the saddle outlet.
6. Use Teflon tape (minimum 2 wraps) on male threads that are threaded into the outlet of the saddle.

### RECOMMENDED HOLE SAW SIZE

3/4" Saddle Outlet	5/8"
1" Saddle Outlet	7/8"
1-1/4" Saddle Outlet	1-1/8"
1-1/2" Saddle Outlet	1-3/8"
2" Saddle Outlet	1-3/4"
3" Saddle Outlet	3"

**Canada**

[www.lateralconnection.com](http://www.lateralconnection.com)

**USA**

**Phone** : 604-856-7253 / 1- 800-993-2599

**Fax** : 604-856-7260 / 1-888-302-7199

**Phone** : 1-877-528-2660

**Fax** : 1-888-302-7199